



Street

Do not cut beyond property line projection

Sawcut all the way through and drill into street using #4 deformed dowel bars at 24" O.C. - 24" long; sawcut in the street shall be made 18" from back of curb

- Approach to be minimum 6" thick, 3000 PSI concrete and install with #3 steel (3/8") at 24" O.C. each way on chairs
- Tie driveway to approach with #4 deformed dowel bars at 24" O.C. - 24" long.
- If over excavated, refill only with approved sand or gravel.
- Approach cannot rest on loose dirt; the subgrade under the new pavement shall be compacted to 95% compaction.
- All dowels smooth bars must be lubricated